

PARQUET IN THE BATHROOM

April 2020

Natural parquet creates a pleasant ambiance in bathrooms

Discover a new source of well-being! A bathroom in harmonious natural and wooden tones always feels pleasantly warm. If the walls and floor are made of real wood, the room temperature you feel is one or two degrees higher than it actually is.

What types of parquet are good for this?

Types of wood that do not swell or shrink much, such as oak and smoked oak, are optimal for this, and should be selected.

Surface treatments by Bauwerk Parkett result in very high surface quality, and are well-suited for installation in bathrooms. However, you should follow a few rules to make sure that you enjoy your Bauwerk parquet for a long time. We generally recommend that you ask the parquet installer to handle its initial treatment. In doing so, you will better protect the untreated joints and edges against the ingress of dirt and moisture.

With oiled surfaces, we recommend regular droplet tests, which make it easy to see if the surface is still sufficiently protected. Regular oiling also helps protect any scratched and damaged areas in the wood.

With this trick, you will quickly find out if you need to re-oil your floor: Let a drop of water fall onto your natural-oiled parquet. If the drop remains tense and compact on the surface, then the parquet floor is fine. If the drop immediately soaks into the wood, the surface should be re-oiled. You can carry out the oiling yourself using Bauwerk Care Oil Eco, or you can hire your parquet installer to do this.

Please follow these tips:

- › Healthy room climate
20 to 22 °C, and 35 to 45% air humidity, with heating
- › Sufficient ventilation
Ventilate the room well after showering or taking a bath.
- › Wipe up any standing moisture
Quickly wipe up any water from the floor after showering or bathing to prevent swelling and water stains in the wood.
- › Underfloor heating
The surface temperature must not exceed 29 °C. The instructions in the 'Information sheet for installation on floors with underfloor heating' must always be followed.
- › Cleaning and care
In addition to normal cleaning and care, we recommend regular droplet testing for bathrooms.
- › Standing moisture
Remove any standing water (e.g. puddles or splashes) after bathing or showering as quickly as possible.



Parquet: Bauwerk Studiopark, Oak Mandorla

For more information, visit: www.bauwerk-parkett.com